


# Reset Password Guide

( ULite Series ) PTZ (HISEE)

1. please find attached tool "IPWizardIII\_2.2.5(English)" and install on your computer.
2. follow the below pic to get Verification code and send us, we will reply you the "Authorization code".



3. input the "Authorization code" to below shown place, click "clear password". It will delete your old password to default, you can log in as normal.

